

Spike Feet Installation Instructions

1. Drill a 3/8" hole into your cabinet for the barbed insert.
2. Place the tapered, bottom portion of the barbed insert into the hole.



3. Screw the spike (point side first) into the insert, leaving half of the threads exposed.



4. Thread the included lock nut onto the spike and down until it stops against the top of the insert.



5. Use the appropriate wrench to screw the barbed insert into the cabinet by turning it clockwise.



6. Once the insert is flush with the speaker cabinet, loosen and remove the nut and spike. The insert will stay in place with most cabinet materials. If the insert begins to back out with the nut, it may be necessary to use a set of pliers to hold the insert in place from the inside of the cabinet while removing the nut.



7. With the nut removed, remove the speaker spike.



8. Your speaker cabinet is now ready for installation of the spike.

